



# DNA II

## Disinfectant, Fungicide, Mildewstat

### Description

This product is formulated to disinfect hard, non-porous surfaces such as: Shower stalls, shower doors and curtains, bathtubs and glazed tiles, chrome plated intakes, toilets, toilet bowls, urinals, portable and chemical toilets and latrine buckets, vanity tops, and restroom fixtures.

### Directions

#### FOR USE AS A GENERAL, HOSPITAL, MEDICAL DISINFECTANT, FUNGICIDE, VIRUCIDE\*:

1. Pre-clean heavily soiled areas.
2. Apply use solution of 1 oz. of this product per gal. of water (or equivalent use dilution) to disinfect hard, non-porous surfaces with a sponge, brush, cloth, mop, by immersion, mechanical spray device, hand pump, coarse pump or trigger spray device. For spray applications, spray 6-8 inches from surface. Do not breathe spray.
3. Treated surfaces must remain wet for 10 minutes.
4. Allow to air dry. Rinsing of floors is not necessary unless they are to be waxed or polished.
5. Prepare a fresh solution daily or when visibly dirty.

For detailed instructions and safety information, please review container label and SDS.



### Features

- **Non-acid**
- **Inhibits bacterial growth**
- **Non-abrasive**

### Applications

**Non-acid disinfectant for:**

- Hospitals
- Public restrooms
- Schools

### Specifications

Color ..... Blue  
 Fragrance..... Fresh  
 pH Range ..... 10.0 - 12.0  
 Dilution .....1 oz./gal.  
 Density.....8.42  
 EPA Registered ..... Yes

### Packaging

ITEM #	SIZE
BSL4410006	6/1 Quart
BSL4410039	2/3 liter



Contact your Account Representative for more information  
 140 Private Brand Way, Athens, TN 37303 | mybrightsolutions.com  
 In case of emergency call Infotrac 800.535.5053  
 © 2018 Midlab, Inc. All right reserved.